UL Product iQ®



Cable Assemblies and Fittings for Industrial Control and Signal Distribution Certified for Canada - Component

COMPANY

DONGGUAN FINECABLES CO LTD

B5 Blk South Industrial Humen Town Dongguan, Guangdong 523900 China

E321413

Marking: Company name model designation, and the Recognized Component Mark for Canada C Note: For additional marking information, refer to the Guide Information Page.

View model for additional information

Model(s): MA12*B***RA, MA12*B***ST, MA12*C***RA, MA12*C***ST, MA12*D***RA, MA12*D***RA, MA12FB*xxRA-MA12FB*xxRA-MA12FB*xxRA-MA12FB*xxRA-MA12FB*xxRA-MA12FB*xxRA-MA12FB*xxRA-MA12FB*xxST-xxx, MA12FB*xxST-xxx, MA12

Model(s): MA12 followed by MS, followed by A, B, C or D, followed by HD or F, followed by 03, 04, 05, 06 or 08, followed by ST or RA, followed by any digit of number, followed by C or R, followed by B, G, O, P or Y, followed by 25 or 34

Model(s): MA12 Series, MA12 followed by M or F, followed by B followed by F, HD or P, followed by 03, 04 or 05, followed by ST or RA, followed by any digit of number, followed by C or R, followed by B, G, O, Y or P, followed by 25 or 34.

Model(s): MA12 Series, MA12 followed by M or F, followed by C followed by F, HD or P, followed by 03, 04, 05 or 06, followed by ST or RA, followed by any digit of number, followed by C or R, followed by B, G, O, Y or P, followed by 25 or 34.

Model(s): MA12 Series, MA12 followed by M or F, followed by D followed by F, HD or P followed by 03 or 04, followed by ST or RA, followed by any digit of number, followed by C or R, followed by B, G, O, Y or P, followed by 25 or 3

Model(s): MA12, followed by FS, followed by A, B, C or D, followed by HD or F, followed by 03, 04, 05, 06 or 08, followed by ST or RA, followed by any digit of number, followed by C or R, followed by B, G, O, P or Y, followed by 25 or 34

Model(s): MA12FC*xxRA-MA12FC*xxRA-xxx where * can be F, HD or P, xx can be 03-06, xxx can be digit extension.	
Model(s): MA12FC*xxRA-MA12FC*xxST-xxx where * can be F, HD or P, xx can be 03-06, xxx can be digit extension.	
Model(s): MA12FC*xxRA-MA12MC*xxST-xxx where * can be F, HD or P, xx can be 03-06, xxx can be digit extension.	
Model(s): MA12FC*xxST-MA12FC*xxST-xxx where * can be F, HD or P, xx can be 03-06, xxx can be digit extension.	
Model(s): MA12FD*xxRA-MA12FD*xxRA-xxx where * can be F, HD or P, xx can be 03-04, xxx can be digit extension.	
Model(s): MA12FD*xxRA-MA12FD*xxST-xxx where * can be F, HD or P, xx can be 03-04, xxx can be digit extension.	
Model(s): MA12FD*xxRA-MA12MD*xxST-xxx where * can be F, HD or P, xx can be 03-04, xxx can be digit extension.	
Model(s): MA12FD*xxST-MA12FD*xxST-xxx where * can be F, HD or P, xx can be 03-04, xxx can be digit extension.	
Model(s): MA12MC*xxRA-MA12FC*xxST-xxx where * can be F, HD or P, xx can be 03-06, xxx can be digit extension.	
Model(s): MA12MC*xxST-MA12FC*xxST-xxx where * can be F, HD or P, xx can be 03-06, xxx can be digit extension.	
Model(s): MA12MD*xxRA-MA12FD*xxST-xxx where * can be F, HD or P, xx can be 03-04, xxx can be digit extension.	
Model(s): MA12MD*xxST-MA12FD*xxST-xxx, where * can be F, HD or P, xx can be 03-04, xxx can be digit extension.	
Model(s): MB12 Series, MB12 followed by M or F, followed by BBFF followed by 03, 04 or 05, followed by ST.	
Model(s): MB12 Series, MB12 followed by M or F, followed by BCFF followed by 03, 04, 05 or 06, followed by ST	
Model(s): MB12 Series, MB12 followed by M or F, followed by BDFF followed by 03 or 04, followed by ST	
Model(s): MB12 Series, MB12 followed by M or F, followed by SAFLF, SAFLHD, SBFLF, SBFLHD, SCFLF, SCFLHD, SDFLF, SDFLHD, followed by blank or -W.	d by 03, 04, 05, 06 or 08, followed by ST, followed
Model(s): MB12, followed by FS, FB or FBS followed by A, B, C or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 06 or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 06 or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 06 or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 06 or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 06 or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 06 or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 06 or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 06 or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 06 or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 06 or D, followed by F or R, followed by F or R	or 08, followed by ST, followed by -2 or -3
Model(s): MB12, followed by MS, MB or MBS followed by A, B, C or D, followed by F or R, followed by HD or F, followed by 03, 04, 05, 0	6 or 08, followed by ST, followed by -2 or -3

Male Cable Assemblies, M12 Series, Model(s): MA12MS#xx04ST-MA12MS#xx04ST-xxx where # can be A, B, C or D, xx can be HD or F, xxx can be digit extension

Male Cable Assemblies, M12 Series, Model(s): MA12MS#xx04ST-RJ45 8P8C plug-xxx where # can be A, B, C or D, xx can be HD or F, xxx can be digit extension

followed by any digit of number, followed by C or R, followed by B, G, O, P or Y, followed by 25 or 34

Female cable fitting, connectors, "M12 series", Model(s): MA12, followed by FS followed by A, B, C or D, followed by HD or F, followed by 03, 04, 05, 06 or 08, followed by ST or RA,

Panel-Mount Fitting, Model(s): MB23MBAFQ0+13ST-6, MB23MSAFQ0+13ST-6, MB23MBAFQ2+13ST-6, MB23MSAFQ2+13ST-6

Panel-mounted inlets/outlets, "MB12 Series", Model(s): MB12 Series, MB12 followed by M or F followed by BAFF, followed by 03, 04, 05 or 08, followed by ST.

Panel-mounted inlets/outlets, "MB12 Series", Model(s): MB12, followed by M or F, followed by BAFF, BAFHD, BBFF, BBFHD, BDFF, BDFHD, followed by 03, 04 or 05, followed by RA

Panel-mounted inlets/outlets, "MB12 Series", Model(s): MB12, followed by M or F, followed by SARF or SAFF, followed by 03, 04, 05 or 08, followed by ST, followed by blank or -W

Panel-mounted inlets/outlets, "MB12 Series", Model(s): MB12, followed by M or F, followed by SBRF or SBFF, followed by 03, 04 or 05, followed by ST, followed by blank or -W

Panel-mounted inlets/outlets, "MB12 Series", Model(s): MB12, followed by M or F, followed by SCRF or SCFF, followed by 03, 04, 05 or 06, followed by ST, followed by blank or -W

Panel-mounted inlets/outlets, "MB12 Series", Model(s): MB12, followed by M or F, followed by SDRF or SDFF, followed by 03 or 04, followed by ST, followed by blank or -W

Last Updated on 2024-08-14

并不是所有出现在本数据库中的公司名称和产品都满足了UL 跟踪检验服务的要求。只有带有 UL 标志的产品,才应该被视为经过UL认证,并满足UL 跟踪检验服务的要求。注意查看产品上的标志。
UL 允许在线认证目录中所含材料的复制遵循以下条件: 1.指南信息、装配、构造、设计、系统和/或认证(文件)必须在不篡改任何数据(或图纸)的情况下完整且无误导性地呈现。2."经 UL 允许从在线 认证目录转载"声明必须出现在所摘取材料的邻近位置。此外,转载材料必须包含以下格式的版权声明: "©2024 UL LLC."